

Immediately clean tools with water after use. Do not start washing off until sufficient joint strength has been achieved. Then wash off the joints with as little water as possible and rinse again. Protect freshly grouted surfaces from drafts, sunlight and rapid drying. This is particularly important for coverings with very narrow joints. Ready for light foot traffic and exposure to rain in 6 hours after installation.

When using high-pressure cleaners, we recommend a V-fin attachment with the moderate use of a surface cleaner without exceeding 1350 PSI of pressure. Preferably, neutral and alkaline cleaners should be used for maintenance cleaning. If permanent chemical stresses are higher than those indicated in the resistance table, the chemical-resistant, 2-component epoxy resin grout and adhesive mortar Okapox royal should be used. To ensure the ideal hydration of the grout, sufficient moisture must be provided.